



SMVector - Frequency Inverter Operating Instructions

Contents



1	Safety Information	3
2	Technical Data 6 2.1 Standards and Application Conditions 6 2.2 Ratings 6 2.2.1 NEMA 1 (IP 31) Ratings 6 2.2.2 NEMA 4X (IP65) Ratings 6 2.3 SMV Type Number Designation 6	; ; ; ; ; ; ; ; ; ; ; ; ; ;
3	Installation 10 3.1 Dimensions and Mounting 10 3.1.1 NEMA 1 (IP31) 10 3.1.2 NEMA 4X (IP65) 1 3.2 Electrical Installation 12 3.2.1 Power Connections 12 3.2.2 Fuses/Cable Cross-Sections 14 3.2.3 Control Terminals 16))))))))))))))
4	Commissioning174.1Local Keypad & Display114.2Drive Displays and Modes of Operation184.3Parameter Setting184.4Electronic Programming Module (EPM)184.5Parameter Menu194.5.1Basic Setup Parameters194.5.2I/O Setup Parameters224.5.3Advanced Setup Parameters244.5.4PID Parameters244.5.5Vector Parameters244.5.6Network Parameters324.5.7Diagnostic Parameters32	, , , , , , , , , , , , , , , , , , ,
5	Troubleshooting and Diagnostics 35 5.1 Status/Warning Messages 34 5.2 Drive Configuration Messages 34 5.3 Fault Messages 34	; 5 5 7

Copyright © 2006 AC Technology Corporation

All rights reserved. No part of this manual may be reproduced or transmitted in any form without written permission from AC Technology Corporation. The information and technical data in this manual are subject to change without notice. AC Technology Corporation makes no warranty of any kind with respect to this material, including, but not limited to, the implied warranties of its merchantability and fitness for a given purpose. AC Technology Corporation assumes no responsibility for any errors that may appear in this manual.

All information given in this documentation has been carefully selected and tested for compliance with the hardware and software described. Nevertheless, discrepancies cannot be ruled out. AC Technology does not accept any responsibility nor liability for damages that may occur. Any necessary corrections will be implemented in subsequent editions. This document is printed in the United States





About These Instructions

This documentation applies to the SMV frequency inverter and contains important technical data regarding the installation, operation, and commissioning of the inverter.

These instructions are only valid for SMV frequency inverters with software revision 20 (see drive nameplate).

Please read the instructions before commissioning.

	A	В	C	D	EF
Lenze ACIECH Made in USA Inverter SMVector	Type: ESV751N0 Id-No: 0000	4TXB 00000 5D81 Q.	IPUT: 3 (3/PE) 400/480 \ 2.9/2.5 A 50-60 HZ	OUTPUT: 3 (3/PE) / 0 - 400/4 2.4/2.1 A 0.75 KW/ 0 - 500 H	For detailed information refer to instruction Manual: SV01 1HP 2 ESV751N04TXB000XX####

Α	В	с	D	E	F
Certifications	Туре	Input Ratings	Output Ratings	Hardware Version	Software Version

Scope of delivery	Important
1 SMV Inverter with EPM installed (see Section 4.4) 1 Operating Instructions	After receipt of the delivery, check immediately whether the items delivered match the accompanying papers. Lenze-AC Tech does not accept any liability for deficiencies claimed subsequently. Claim: • visible transport damage immediately to the forwarder. • visible deficiencies /incompleteness immediately to your Lenze-AC Tech representative



Safety Information

|--|

1 Safety Information

General

Some parts of Lenze-AC Tech controllers can be electrically live and some surfaces can be hot. Non-authorized removal of the required cover, inappropriate use, and incorrect installation or operation creates the risk of severe injury to personnel or damage to equipment.

All operations concerning transport, installation, and commissioning as well as maintenance must be carried out by qualified, skilled personnel who are familiar with the installation, assembly, commissioning, and operation of variable frequency drives and the application for which it is being used.

Installation

Ensure proper handling and avoid excessive mechanical stress. Do not bend any components and do not change any insulation distances during transport, handling, installation or maintenance. Do not touch any electronic components or contacts. This drive contains electrostatically sensitive components, which can easily be damaged by inappropriate handling. Static control precautions must be adhered to during installation, testing, servicing and repairing of this drive and associated options. Component damage may result if proper procedures are not followed.

MARNING! Drives mus combustible excessive v

Drives must not be installed where subjected to adverse environmental conditions such as: combustible, oily, or hazardous vapors or dust; corrosive chemicals; excessive moisture; excessive vibration; direct sunlight or extreme temperatures. Contact Lenze-AC Tech for more information.

This drive has been tested by Underwriters Laboratory (UL) and is an approved component in compliance with UL508C Safety Standard. This drive must be installed and configured in accordance with both national and international standards. Local codes and regulations take precedence over recommendations provided in this and other Lenze-AC Tech documentation.

The SMVector drive is considered a component for integration into a machine or process. It is neither a machine nor a device ready for use in accordance with European directives (reference machinery directive and electromagnetic compatibility directive). It is the responsibility of the end user to ensure that the machine meets the applicable standards.

Electrical Connection

When working on live drive controllers, applicable national safety regulations must be observed. The electrical installation must be carried out according to the appropriate regulations (e.g. cable cross-sections, fuses, protective earth [PE] connection). While this document does make recommendations in regards to these items, national and local codes must be adhered to.

The documentation contains information about installation in compliance with EMC (shielding, grounding, filters and cables). These notes must also be observed for CE-marked controllers. The manufacturer of the system or machine is responsible for compliance with the required limit values demanded by EMC legislation.

Application

The drive must not be used as a safety device for machines where there is a risk of personal injury or material damage. Emergency Stops, over-speed protection, acceleration and deceleration limits, etc must be made by other devices to ensure operation under all conditions.

The drive does feature many protection devices which are aimed at protecting the drive and the driven equipment by generating a fault and shutting the drive and motor down by removing power. Mains power variances can also result in shutdown of the drive. When the fault condition disappears or is cleared, the drive can be configured to automatically restart, it is the responsibility of the user and/or OEM and/or integrator to ensure that the drive is configured for safe operation.





Safety Information

Explosion Proof Applications

Explosion proof motors that are not rated for inverter use lose their certification when used for variable speed. Due to the many areas of liability that may be encountered when dealing with these applications, the following statement of policy applies:

AC Technology Corporation inverter products are sold with no warranty of fitness for a particular purpose or warranty of suitability for use with explosion proof motors. AC Technology Corporation accepts no responsibility for any direct, incidental or consequential loss, cost or damage that may arise through the use of AC inverter products in these applications. The purchaser expressly agrees to assume all risk of any loss, cost or damage that may arise from such application.

Operation

Systems including controllers must be equipped with additional monitoring and protection devices according to the corresponding standards (e.g. technical equipment, regulations for prevention of accidents, etc.). The controller may be adapted to your application as described in this documentation.

DANGER!

- After the controller has been disconnected from the supply voltage, live components and power connection must not be touched immediately, since capacitors could be charged. Please observe the corresponding notes on the controller.
- Please close all protective covers and doors prior to and during operation.
- Do not cycle input power to the controller more than once every two minutes.

Safety Notifications

All safety information given in these Operating Instructions has the same layout:

.. . .

Â	Note (describes the dange	er and informs on he	le danger) ow to proceed)
lcon		Signal Words	
Â	Warning of hazardous electrical voltage	DANGER!	Warns of impending danger. Consequences if disregarded: Death or severe injuries.
\triangle	Warning of a general danger	WARNING!	Warns of potential, very hazardous situations. Consequences if disregarded: Death or severe injuries.
STOP	Warning of damage to equipment	STOP!	Warns of potential damage to material and equipment. Consequences if disregarded: Damage to the controller/drive or its environ- ment.
1	Information	NOTE	Designates a general, useful note. If observed, then using the controller/drive system is made easier.



Safety Information

Safety Notifications in accordance with EN 61800-5-1:

DANGER! Hazard of Electrical Shock

Capacitors retain charge for approximately 180 seconds after power is removed. Allow at least 3 minutes for discharge of residual charge before touching the drive.

i	

NOTE

Control and communications terminals provide reinforced insulation when the drive is connected to a power system rated up to 300V rms between phase to ground (PE) and the applied voltage on Terminals 16 and 17 is less than 150VAC between phase and ground.

Safety Notifications in accordance with UL:

Note for UL approved system with integrated controllers: UL warnings are notes which apply to UL systems. The documentation contains special information about UL.



- Suitable for use on a circuit capable of delivering not more than 200,000 rms
- symmetrical amperes, at the maximum voltage rating marked on the drive.
- Use minimum 75 °C copper wire only.
 - · Shall be installed in a pollution degree 2 macro-environment.





2 Technical Data

2.1 Standards and Application Conditions

Conformity	CE	Low Voltage (73/23/El	EC) & EMC (89/336/EEC) Directives		
Approvals	UL508C	Underwriters Laborato	ries -Power Conversion Equipment		
Input voltage phase imbalance	<u>≤</u> 2%				
Humidity	\leq 95% non-condens	sing			
	Transport	-25 +70°C			
Temperature range	Storage	-20 +70°C	-20 +70°C		
	Operation	-10 +55°C (with 2.5%/°C current derating above +40°C)			
Installation height	0 - 4000m a.m.s.l. (with 5%/1000 m current derating above 1000m a.m.s.l.)				
Vibration resistance	acceleration resistant up to 1.0g				
🕂 Earth leakage current	> 3.5 mA to PE				
Enclosure	IP31/NEMA 1 IP65/NEMA 4X IP54/NEMA 12				
Protection measures against	short circuit, earth fault, phase loss, over voltage, under voltage, motor stalling, over temperature, motor overload				

2.2 Ratings

2.2.1 NEMA 1 (IP 31) Ratings

120VAC Doubler / 240VAC Models

Туре	Power	Mains			Outpu	t Current	Watta
	[Hp/kW]	Voltage ⁽¹⁾	l _{in} (120V)	l _{in} (240V)	I _n	CLim _{max} ⁽²⁾	Loss
ESV251N01SXB	0.33 / 0.25	120 V Single-phase (1/N/PE)	6.8	3.4	1.7	200	24
ESV371N01SXB	0.5 / 0.37	(90 132 V) OR	9.2	4.6	2.4	200	32
ESV751N01SXB	1 / 0.75	240 V Single-phase (2/PE) (170 264 V)	16.6	8.3	4.2	200	52

240VAC Models

Туре	Power	Mains			Outpu	t Current	
	[Hp/kW]	Voltage ⁽¹⁾	l _{in} 1~ (2/PE)	l _{in} 3~ (3/PE)	I _n	CLim _{max} ⁽²⁾	Loss
ESV251N02SXB	0.33 / 0.25	240 V Single Phase (2/PE)	3.4	-	1.7	200	20
ESV371N02YXB	0.5 / 0.37	240 V Single-phase (2/PE) OR 240 V Three-phase (3/PE) (170 264 V)	5.1	2.9	2.4	200	27
ESV751N02YXB	1/0.75		8.8	5.0	4.2	200	41
ESV112N02YXB	1.5 / 1.1		12.0	6.9	6.0	200	64
ESV152N02YXB	2 / 1.5		13.3	8.1	7.0	200	75
ESV222N02YXB	3 / 2.2		17.1	10.8	9.6	200	103



Technical Data



Туре	Power	Mains	Outpu							
1	[Hp/kW]	Voltage ⁽¹⁾	l _{in} 1~ (2/PE)	l _{in} 3~ (3/PE)	I,	CLim _{max} ⁽²⁾	Loss			
ESV112N02TXB	1.5 / 1.1		-	6.9	6.0	200	64			
ESV152N02TXB	2/1.5		-	8.1	7.0	200	75			
ESV222N02TXB	3 / 2.2	240 V Three-phase (3/PE)	-	10.8	9.6	200	103			
ESV402N02TXB	5 / 4.0	(170 V 264 V)	-	18.6	16.5	200	154			
ESV552N02TXB	7.5 / 5.5		-	26	23	200	225			
ESV752N02TXB	10/7.5		-	33	29	200	274			

480VAC Models

Туре	Power	Mains			Output Current				
	[Hp/kW]	Voltage ⁽¹⁾	I	in	I,		CLim _{max} ⁽³⁾		Watts
			400V	480V	400V	480V	400V	480V	Loss
ESV371N04TXB	0.5 / 0.37		1.7	1.5	1.3	1.1	175	200	23
ESV751N04TXB	1/0.75		2.9	2.5	2.4	2.1	175	200	37
ESV112N04TXB	1.5 / 1.1	400 V Three-phase (3/PE)	4.2	3.6	3.5	3.0	175	200	48
ESV152N04TXB	2 / 1.5	(340 440 V)	4.7	4.1	4.0	3.5	175	200	57
ESV222N04TXB	3 / 2.2	480 V Three-phase (3/PE)	6.1	5.4	5.5	4.8	175	200	87
ESV402N04TXB	5 / 4.0	(340 528 V)	10.6	9.3	9.4	8.2	175	200	128
ESV552N04TXB	7.5 / 5.5		14.2	12.4	12.6	11.0	175	200	178
ESV752N04TXB	10 / 7.5		18.1	15.8	16.1	14.0	175	200	208

600VAC Models

Туре	Power	Mains		Output C	utput Current		
	[Hp/kW]	Voltage ⁽¹⁾	l _{in}	I _n	CLim _{max} ⁽²⁾	Loss	
ESV751N06TXB	1 / 0.75		2.0	1.7	200	37	
ESV152N06TXB	2/1.5		3.2	2.7	200	51	
ESV222N06TXB	3 / 2.2	600 V Three-phase (3/PE)	4.4	3.9	200	68	
ESN402N06TXB	5 / 4.0	(425 660 V)	6.8	6.1	200	101	
ESV552N06TXB	7.5 / 5.5		10.2	9	200	148	
ESV752N06TXB	10 / 7.5		12.4	11	200	172	

(1) Frequency Range: 48 Hz ... 62 Hz

- (2) Current Limit (CLim) is a percentage of the output current, I_n. CLim_{max} is the maximum setting for P171.
- (3) Current Limit (CLim) is a percentage of the output current, I_n. CLim_{max} is the maximum setting for P171. For 480VAC models, the CLim_{max} value in the 480V column of the table is used when P107 is set to 1. The CLim_{max} value in the 400V column is used when P107 is set to 0.

STOP	STOP! • For installations above 1000m a.m.s.l., derate I _n by 5% per 1000m, do not exceed 4000m a.m.s.l. • Operation above 40°C, derate I _n by 2.5% per °C, do not exceed 55°C. • Carrier Frequency (P166): • If P166=2 (8 kHz), derate I _n to 92% of drive rating • If P166=3 (10 kHz), derate I _n to 84% of drive rating
------	--





2.2.2 NEMA 4X (IP65) Ratings

240VAC Models

Туре	Power	Mains		Output Current			
	[Hp/kW]	Voltage ⁽¹⁾	l _{in} 1~ (2/PE)	l _{in} 3~ (3/PE)	I _n	CLim _{max} ⁽²⁾	Loss
ESV371N02SFC	0.5 / 0.37		5.1	-	2.4	200	26(5)
ESV751N02SFC	1/0.75	240 V Single Phase (2/PE)	8.8	-	4.2	200	38(5)
ESV112N02SFC	1.5 / 1.1		12.0	-	6.0	200	59(5)
ESV152N02SFC	2/1.5	(integrar intere)	13.3	-	7.0	200	69(5)
ESV222N02SFC	3 / 2.2		17.1	-	9.6	200	93(5)
ESV371N02YXC	0.5 / 0.37	240 V Single-phase (2/PE)	5.1	2.9	2.4	200	26
ESV751N02YXC	1/0.75	OR	8.8	5.0	4.2	200	38
ESV112N02YXC	1.5 / 1.1	240 V Three-phase (3/PE)	12.0	6.9	6.0	200	59
ESV152N02YXC	2/1.5	(170 264 V)	13.3	8.1	7.0	200	69
ESV222N02YXC	3 / 2.2	(No Filters)	17.1	10.8	9.6	200	93

480VAC Models

Туре	Power	Mains			Output Current				
	[Hp/kW]	Voltage ⁽¹⁾	I _{in}		I,		CLim _{max} ⁽³⁾		Watts
			400V	480V	400V	480V	400V	480V	Loss
ESV371N04T_C (4)	0.5 / 0.37	400 V Three-phase (3/PE)	1.7	1.5	1.3	1.1	175	200	21(5)
ESV751N04T C (4)	1/0.75	(340 440 V)	2.9	2.5	2.4	2.1	175	200	33(5)
ESV112N04T C (4)	1.5 / 1.1	OR	4.2	3.6	3.5	3.0	175	200	42(5)
ESV152N04T C (4)	2/1.5	480 V Three-phase (3/PE)	4.7	4.1	4.0	3.5	175	200	50(5)
ESV222N04T C (4)	3 / 2.2	(340 528 V)	6.1	5.4	5.5	4.8	175	200	78(5)

600VAC Models

Туре	Power	Mains Output Current					
	[Hp/kW]	Voltage ⁽¹⁾	l _{in}	I _n	CLim _{max} ⁽²⁾	Loss	
ESV751N06TXC	1.0 / 0.75	000) (Thurson has a (0/DE)	2.0	1.7	200	31	
ESV152N06TXC	1.5 / 1.1	(425 660 V)	3.2	2.7	200	43	
ESV222N06TXC	3.0 / 2.2		4.4	3.9	200	57	

(1) Frequency Range: 48 Hz ... 62 Hz

(2) Current Limit (CLim) is a percentage of the output current, I_n. CLim_{max} is the maximum setting for P171.

(3) Current Limit (CLim) is a percentage of the output current, Iⁿ_n. CLim^{max}_{max} is the maximum setting for P171. For 480VAC models, the CLim_{max} value in the 480V column of the table is used when P107 is set to 1. The CLim_{max} value in the 400V column is used when P107 is set to 0.

(4) The 11th digit of the Type number shown as a blank "_" is either an "F" = integral EMC filter or an "X" = no filter.

(5) For models with integral filters (those with an "F" in the 11th digit of the Type number) add 3 watts to the rated "Watts Loss" value.

STOP	STOP! • For installations above 1000m a.m.s.l., derate l _n by 5% per 1000m, do not exceed 4000m a.m.s.l. • Operation above 40°C, derate l _n by 2.5% per °C, do not exceed 55°C. • Carrier Frequency (P166): • If P166=1 (6 kHz), derate l _n to 92% of drive rating • If P166=2 (8 kHz), derate l _n to 82% of drive rating
	- If P166=2 (8 KHz), derate I_n to 84% of drive rating - If P166=3 (10 kHz), derate I_n to 76% of drive rating







2.3 SMV Type Number Designation

The table herein describes the Type numbering desgination for the SMVector Inverter models.

	ESV	152	NO	2	Т	Х	В
Electrical Products in the SMVector Serie	S						
Power Rating in kW:							
251 = 0.25kW (0.33HP)	402 = 4	.0kW (5HP)					
371 = 0.37kW (0.5HP)	552 = 5	.5kW (7.5HP)					
751 = 0.75kW (1HP)	752 = 7	.5kW (10HP)					
112 = 1.1kW (1.5HP)							
152 = 1.5kW (2HP)							
222 = 2.2kW (3HP)							
Installed Communication Module:			-				
C0 = CANopen							
D0 = DeviceNet							
R0 = RS-485 / ModBus							
N0 = Communications not installed							
Input Voltage:							
1 = 120 VAC (doubler output) or 240	VAC						
2 = 240 VAC							
4 = 400/480 VAC							
6 = 600 VAC							
Input Phase:							
S = Single Phase Input only							
Y = Single or Three Phase Input							
T = Three Phase Input only							
Input Line Filter							
F = Integral EMC Filter							
X = Without EMC Filter							
Enclosure:							
B = NEMA 1 (IP31)							
C = NEMA 4X (IP65)							
D = NEMA 12 (IP54)							





3 Installation

3.1 Dimensions and Mounting

3.1.1 NEMA 1 (IP31)



V0102

Туре	a	a1	b	b1	b2	c	s1	s2	m
	in (mm)	in (mm)	in (mm)	in (mm)	in (mm)	in (mm)	in (mm)	in (mm)	Ib (kg)
ESV251~~~~~B ESV371~~~~~B ESV751~~~~~B	3.90 (99)	3.10 (79)	7.50 (190)	7.00 (178)	0.25 (6)	4.35 (110)	0.6 (15)	2.0 (50)	2.0 (0.9)
ESV112~~~~B ESV152~~~~B ESV222~~~~B	3.90 (99)	3.10 (79)	7.50 (190)	7.00 (178)	0.25 (6)	5.45 (138)	0.6 (15)	2.0 (50)	2.8 (1.3)
ESV402~~~~B	3.90	3.10	7.50	7.00	0.25	5.80	0.6	2.0	3.2
	(99)	(79)	(190)	(178)	(6)	(147)	(15)	(50)	(1.5)
ESV552~~~~B	5.12	4.25	9.83	9.30	0.25	6.30	0.6	2.0	6.0
ESV752~~~~B	(130)	(108)	(250)	(236)	(6)	(160)	(15)	(50)	(2.0)



WARNING!

Drives must not be installed where subjected to adverse environmental conditions such as: combustible, oily, or hazardous vapors or dust; corrosive chemicals; excessive moisture; excessive vibration; direct sunlight or extreme temperatures. Contact Lenze-AC Tech for more information.



3.1.2 NEMA 4X (IP65)







V0123

Туре	a in (mm)	a1 in (mm)	b in (mm)	b1 in (mm)	b2 in (mm)	c in (mm)	s1 in (mm)	s2 in (mm)	m Ib (kg)
ESV371N02YXC	6.28 (160)	5.90 (150)	8.00 (203)	6.56 (167)	0.66 (17)	4.47 (114)	2.00 (51)	2.00 (51)	2.9 (1.32)
ESV751N02YXC	6.28 (160)	5.90 (150)	8.00 (203)	6.56 (167)	0.66 (17)	4.47 (114)	2.00 (51)	2.00 (51)	2.9 (1.32)
ESV112N02YXC	6.28 (160)	5.90 (150)	8.00 (203)	6.56 (167)	0.72 (18)	6.27 (159)	2.00 (51)	2.00 (51)	5.1 (2.31)
ESV152N02YXC	6.28 (160)	5.90 (150)	8.00 (203)	6.56 (167)	0.72 (18)	6.27 (159)	2.00 (51)	2.00 (51)	5.3 (2.40)
ESV222N02YXC	7.12 (181)	6.74 (171)	8.00 (203)	6.56 (167)	0.72 (18)	6.77 (172)	2.00 (51)	2.00 (51)	6.5 (2.95)
ESV371N04TXC	6.28 (160)	5.90 (150)	8.00 (203)	6.56 (167)	0.66 (17)	4.47 (114)	2.00 (51)	2.00 (51)	3.0 (1.36)
ESV751N04TXC	6.28 (160)	5.90 (150)	8.00 (203)	6.56 (167)	0.66 (17)	4.47 (114)	2.00 (51)	2.00 (51)	3.0 (1.36)
ESV112N04TXC	6.28 (160)	5.90 (150)	8.00 (203)	6.56 (167)	0.72 (18)	6.27 (159)	2.00 (51)	2.00 (51)	5.2 (2.36)
ESV152N04TXC	6.28 (160)	5.90 (150)	8.00 (203)	6.56 (167)	0.72 (18)	6.27 (159)	2.00 (51)	2.00 (51)	5.2 (2.36)
ESV222N04TXC	6.28 (160)	5.90 (150)	8.00 (203)	6.56 (167)	0.72 (18)	6.27 (159)	2.00 (51)	2.00 (51)	5.3 (2.40)
ESV751N06TXC	6.28 (160)	5.90 (150)	8.00 (203)	6.56 (167)	0.66 (17)	4.47 (114)	2.00 (51)	2.00 (51)	3.0 (1.36)
ESV152N06TXC	6.28 (160)	5.90 (150)	8.00 (203)	6.56 (167)	0.72 (18)	6.27 (159)	2.00 (51)	2.00 (51)	5.3 (2.40)
ESV222N06TXC	6.28 (160)	5.90 (150)	8.00 (203)	6.56 (167)	0.72 (18)	6.27 (159)	2.00 (51)	2.00 (51)	5.3 (2.40)
ESV371N02SFC	6.28 (160)	5.90 (150)	8.00 (203)	6.56 (167)	0.66 (17)	4.47 (114)	2.00 (51)	2.00 (51)	3.5 (1.59)
ESV751N02SFC	6.28 (160)	5.90 (150)	8.00 (203)	6.56 (167)	0.66 (17)	4.47 (114)	2.00 (51)	2.00 (51)	3.5 (1.59)
ESV112N02SFC	6.28 (160)	5.90 (150)	8.00 (203)	6.56 (167)	0.72 (18)	6.27 (159)	2.00 (51)	2.00 (51)	5.7 (2.58)
ESV152N02SFC	6.28 (160)	5.90 (150)	8.00 (203)	6.56 (167)	0.72 (18)	6.27 (159)	2.00 (51)	2.00 (51)	5.9 (2.68)
ESV222N02SFC	7.12 (181)	6.74 (171)	8.00 (203)	6.56 (167)	0.72 (18)	6.27 (159)	2.00 (51)	2.00 (51)	6.5 (2.96)
ESV371N04TFC	6.28 (160)	5.90 (150)	8.00 (203)	6.56 (167)	0.66(17)	6.77 (172)	2.00 (51)	2.00 (51)	3.5 (1.59)
ESV751N04TFC	6.28 (160)	5.90 (150)	8.00 (203)	6.56 (167)	0.66 (17)	4.47 (114)	2.00 (51)	2.00 (51)	3.6 (1.63)
ESV112N04TFC	6.28 (160)	5.90 (150)	8.00 (203)	6.56 (167)	0.72 (18)	6.27 (159)	2.00 (51)	2.00 (51)	5.7 (2.58)
ESV152N04TFC	6.28 (160)	5.90 (150)	8.00 (203)	6.56 (167)	0.72 (18)	6.27 (159)	2.00 (51)	2.00 (51)	5.7 (2.58)
ESV222N04TFC	6.28 (160)	5.90 (150)	8.00 (203)	6.56 (167)	0.72 (18)	6.27 (159)	2.00 (51)	2.00 (51)	5.8 (2.63)



WARNING!

Drives must not be installed where subjected to adverse environmental conditions such as: combustible, oily, or hazardous vapors or dust; corrosive chemicals; excessive moisture; excessive vibration; direct sunlight or extreme temperatures. Contact Lenze-AC Tech for more information.





3.2 Electrical Installation

3.2.1 Power Connections

DANGER!

Hazard of electrical shock! Circuit potentials are up to 600 VAC above earth ground. Capacitors retain charge after power is removed. Disconnect power and wait at least three minutes before servicing the drive.



Mains and Motor Terminations

12 lb-in (1.3 Nm)

0.25 in (6mm)

3.2.1.1 Mains Connection to 120VAC Single-Phase Supply



3.2.1.2 Mains Connection to 240VAC Single-Phase Supply





3.2.1.3 Mains Connection to Three-Phase Supply



3.2.1.4 Motor Connection





WARNING!

Leakage current may exceed 3.5 mA AC. The minimum size of the protective earth (PE) conductor shall comply with local safety regulations for high leakage current equipment.

3.2.1.5 Installation Recommendations for EMC Compliance

For compliance with EN 61800-3 or other EMC standards, motor cables, line cables and control or communications cables must be shielded with each shield/screen clamped to the drive chassis. This clamp is typically located at the conduit mounting plate.

Motor cable should be low capacitance (core/core <75pF/m, core/shield <150pF/m). Filtered drives can meet the class A limits of EN 55011 and EN 61800-3 Category 2 with this type of motor cable up to 10 meters.

Any external line filter should have its chassis connected to the drive chassis by mounting hardware or with the shortest possible wire or braid.





3.2.1.6 NEMA 4X (IP 65) Input Terminal Block

For NEMA 4X models with an integrated EMC filter, the input terminal block is located on the right-hand side of the SMV inverter in the NEMA 4X (IP 65) enclosure. The Single and Three Phase models are illustrated herein. Refer to paragraph 3.2.3 Control Terminals for pin out information.

Single Phase (2/PE) with Filter



Three Phase (3/PE) with Filter







3.2.2 Fuses/Cable Cross-Sections

NOTE



Observe local regulations. Local codes may supersede these recommendations

		Recommendations							
	Туре	Fuse	Miniature circuit	Fuse ⁽²⁾ or Breaker ⁽³⁾	Input Pov (L1, L2,	ver Wiring L3, PE)			
		M10.A C10.A		(N. America)	[mm ²]	[AWG]			
120V	ESV251N01SXB	M10 A	C10 A	10 A	1.5	14			
120V 1~ (1/N/PE)	ESV371N01SXB	M16 A	C16 A	15 A	2.5	14			
	ESV751N01SXB	M25 A	C25 A	25 A	4	10			
	ESV251N01SXB, ESV251N02SXB ESV371N01SXB, ESV371N02YXB ESV371N02SFC	M10 A	C10 A	10 A	1.5	14			
240V	ESV751N01SXB, ESV751N02YXB ESV751N02SFC	M16 A	C16 A	15 A	2.5	14			
(2/PE)	ESV112N02YXB, ESV112N02SFC	M20 A	C20 A	20 A	2.5	12			
	ESV152N02YXB, ESV152N02SFC	M25 A	C25 A	25 A	2.5	12			
	ESV222N02YXB, ESV222N02SFC	M32 A	C32A	32 A	4	10			
	ESV371N02YXB, ESV751N02YXB ESV371N02YXC, ESV751N02YXC	M10 A	C10 A	10 A	1.5	14			
240V	ESV112N02YXB, ESV152N02YXB ESV112N02TXB, ESV152N02TXB ESV112N02YXC, ESV152N02YXC	M16 A	C16 A	12 A	1.5	14			
3~ (3/PE)	ESV222N02YXB, ESV222N02TXB ESV222N02YXC	M20 A	C20 A	20 A	2.5	12			
	ESV402N02TXB	M32 A	C32 A	32 A	4.0	10			
	ESV552N02TXB	M40 A	C40 A	35 A	6.0	8			
	ESV752N02TXB	M50 A	C50 A	45 A	10	8			
400V	ESV371N04TXBESV222N04TXB ESV371N04TXCESV222N04TXC ESV371N04TFC ESV222N04TFC	M10 A	C10 A	10 A	1.5	14			
or 480V	ESV402N04TXB	M16 A	C16 A	20 A	2.5	14			
3~(3/PE)	ESV552N04TXB	M20 A	C20 A	20 A	2.5	14			
	ESV752N04TXB	M25 A	C25 A	25 A	4.0	10			
	ESV751N06TXBESV222N06TXB ESV751N06TXCESV222N06TXC	M10 A	C10 A	10 A	1.5	14			
600V	ESV402N06TXB	M16 A	C16 A	12 A	1.5	14			
3~(3/PE)	ESV552N06TXB	M16 A	C16 A	15 A	2.5	14			
	ESV752N06TXB	M20 A	C20 A	20 A	2.5	12			

(1) Installations with high fault current due to large supply mains may require a type D circuit breaker.

(2) UL Class CC or T fast-acting current-limiting type fuses, 200,000 AIC, preferred. Bussman KTK-R, JJN or JJS or equivalent.

(3) Thermomagnetic type breakers preferred.

Observe the following when using Ground Fault Circuit Interrupters (GFCIs):

- Installation of GFCI only between supplying mains and controller.
- The GFCI can be activated by:
 - capacitive leakage currents between the cable screens during operation (especially with long, screened motor cables)
 - connecting several controllers to the mains at the same time
 - RFI filters





3.2.3 Control Terminals

i

NOTE

NOTE
Control and communications terminals provide reinforced insulation when the drive is
connected to a power system rated up to 300V rms between phase to ground and the
applied voltage on Terminals 16 and 17 is less than 150VAC between phase and ground.

Terminal	Description	Important		
1	Digital Input: Start/Stop	input resistance = $4.3k\Omega$		
2	Analog Common			
5	Analog Input: 010 VDC	input resistance: >50 k Ω		
6	Internal DC supply for speed pot	+10 VDC, max. 10 mA		
25	Analog Input: 420 mA	input resistance: 250Ω		
4	Digital Reference/Common	+15 VDC / 0 VDC, depending on assertion level		
11	Internal DC supply for external devices	+12 VDC, max. 50 mA		
13A	Digital Input: Configurable with P121			
13B	Digital Input: Configurable with P122	input resistance = $4.3k\Omega$		
13C	Digital Input: Configurable with P123			
14	Digital Output: Configurable with P142	DC 24 V / 50 mA; NPN		
30	Analog Output: Configurable with P150P155	010 VDC, max. 20 mA		
16	Delay autout, Configurable with D140	AC 250 V / 3 A		
17	Relay output: configurable with P140	DC 24 V / 2 A 240 V / 0.22 A, non-inductive		



Assertion level of digital inputs

The digital inputs can be configured for active-high or active-low by setting the Assertion Level Switch (ALsw) and P120. If wiring to the drive inputs with dry contacts or with PNP solid state switches, set the switch and P120 to "High" (+). If using NPN devices for inputs, set both to "Low" (-). Active-high (+) is the default setting.

 $HIGH = +12 \dots +30 V$ LOW = 0 \ldots +3 V

NOTE



An F_RL fault will occur if the Assertion Level switch (ALsw) position does not match the parameter P120 setting and P100 or any of the digital inputs (P121...P123) is set to a value other than 0.







4.1 Local Keypad & Display





START BUTTON:

In Local Mode (P100 = 0, 4), this button will start the drive.



WARNING!

When JOG is active, the STOP button will not stop the drive!



ROTATION:

In Local Mode (P100 = 0, 4), this selects the motor rotation direction:

STOP BUTTON: stops the drive, regardless of which mode the drive is in.

- The LED for the present rotation direction (FWD or REV) will be on
- Press R/F; the LED for the opposite rotation direction will blink
- Press M within 4 seconds to confirm the change
- The blinking direction LED will turn on, and the other LED will turn off

When rotation direction is changed while the drive is running, the commanded direction LED will blink until the drive is controlling the motor in the selected direction.



MODE:

Used to enter/exit the Parameter Menu when programming the drive and to enter a changed parameter value.



UP AND DOWN BUTTONS:

Used for programming and can also be used as a reference for speed, PID setpoint, or torque setpoint.

When the ▲ and ▼ buttons are the active reference, the middle LED on the left side of the display will be on.

INDICATING LEDs

FWD/REV LEDs: Indicate the present rotation direction. See ROTATION above.

AUTO LED: Indicates that the drive has been put into Auto mode from one of the TB13 inputs (P121...P123 set to 1...7).

Also indicates that PID mode is active (if enabled).

RUN LED: Indicates that the drive is running

NOTE

 \blacktriangle \blacktriangledown LED: Indicates that the \blacktriangle \blacktriangledown are the active reference.



If the keypad is selected as the auto reference (P121...P123 is 6) and the corresponding TB-13 input is closed, then the AUTO LED and $\blacktriangle \lor$ LEDs will both be on.





4.2 Drive Displays and Modes of Operation

Speed Mode Display

In the standard mode of operation, the drive frequency output is set directly by the selected reference (keypad, analog reference, etc.). In this mode, the drive display will show the drive's output frequency.

PID Mode Display

When the PID mode is enabled and active, the normal run display shows the actual PID setpoint. When PID mode is not active, the display returns to showing the drive's output frequency.

Torque Mode Display

When the drive is operating in Vector Torque mode, the normal run display shows the drive's output frequency.

4.3 Parameter Setting



4.4 Electronic Programming Module (EPM)

The EPM contains the drives operational memory. Parameter settings are stored in the EPM and setting changes are made to the "User settings" in the EPM.

An optional EPM Programmer (model EEPM1RA) is available that allows:

- An EPM to be copied directly to another EPM.
- An EPM to be copied to the memory of the EPM Programmer.
- Stored files can be modified in the EPM Programmer.
- Stored files can be copied to another EPM.

As the EPM Programmer is battery operated, parameter settings can be copied to an EPM and inserted into a drive without power being applied to the drive. This means that the drive will be fully operational with the new settings on the next application of power.

Additionally, when the drives parameter settings are burned into an EPM with the EPM Programmer, the settings are saved in two distinct locations; the "User settings" and the "OEM default settings". While the User settings can be modified in the drive, the OEM settings cannot. Thus, the drive can be reset not only to the "factory" drive default settings (shown in this manual), but can be set to the Original Machine settings as programmed by the OEM.

While the EPM can be removed for copying or to use in another drive, it must be installed for the drive to operate (a missing EPM will trigger an $F_{-}F$ I fault).



EPM Module in SMV Drive







4.5 Parameter Menu

4.5.1 Basic Setup Parameters

Code		Possibl	e Settings	IMPORTANT
No.	Name	Default	Selection	IMPORTANT
P 100	Start Control Source	0	0 Local Keypad	Use RUN button on front of drive to start
			1 Terminal Strip	Use start/stop circuit wired into the terminal strip. Refer to Section 3.2.3
			2 Remote Keypad Only	Use RUN button on optional Remote Keypad to start
			3 Network Only	 Start command must come from network (Modbus, CANopen, etc) Requires optional communication module (refer to the network module documentation). Must also set one of the TB-13 inputs to 9 (Network Enable); refer to P121P123
			4 Terminal Strip or Local Keypad	Allows start control to be switched between terminal strip and local keypad using one of the TB-13 inputs. See note below.
			5 Terminal Strip or Remote Keypad	Allows start control to be switched between terminal strip and optional remote keypad using one of the TB-13 inputs. See note below.
			WARNING! P100 = 0 disables TB-1 as a STOP input! are reset back to defaults (see P199)	STOP circuitry may be disabled if parameters
		İ	 NOTE P100 = 4, 5: To switch between control Select TB-13x OPEN (or not configured): Term TB-13x CLOSED: Local (P100 = 4) or f P100 = 0, 1, 4: Network can take con TB-13x input is CLOSED. The STOP button on the front of the dr An F_RL fault will occur if the Assematch the P120 setting and P100 is 	rol sources, one of the TB-13 inputs (P121 ct); ninal strip control Remote (P100 = 5) keypad trol if P121P123 = 9 and the corresponding ive is always active except in JOG mode. tion Level switch (ALsw) position does not a set to a value other than 0.
P 10 I	Standard Reference	0	0 Keypad (Local or Remote)	Selects the default speed or torque reference
	Source		1 0-10 VDC	when no Auto Reference is selected using the
2 4-20 mA		2 4-20 mA	TD-13 lilputs	
			3 Preset #1	
			4 Preset #2	
			5 Preset #3	
6 Network				





Code		Possibl	e Settings		IMPOPTANT
No.	Name	Default	Selection		INFORTANT
P 102	Minimum Frequency	0.0	0.0 {Hz}	P103	P102, P103 are active for all speed
P 103	Maximum Frequency	60.0	7.5 {Hz}	500	 When using an analog speed reference, also see P160, P161
		i	 NOTE P103 cannot be set To set P103 above 1 Scroll up to 120 Hz Release s button aga Press s button agar 	below Minimum Fr 20 Hz: z; display shows H nd wait one secon in to continue incre	requency (P102) "Fr (flashing). d easing P103
	WARNING! Consult motor/machin cause damage to equ	ie manufac ipment and	cturer before operating a 1 injury to personnel!	bove rated frequer	ncy. Overspeeding the motor/machine may
P 104	Acceleration Time 1	20.0	0.0 {s}	3600	 P104 = time of frequency change from 0 Hz to P167 (base frequency) P105 = time of frequency change from
P 105	Deceleration Time 1	20.0	0.0 {s}	3600	 P167 to 0 Hz For S-ramp accel/decel, adjust P106
i	Example: if $P103 = 1$ to 120 Hz = 40.0 s	20 Hz, P10	04 = 20.0 s and P167 (b	ase frequency) = 6	60 Hz; the rate of frequency change from 0 Hz
P 106	S-Ramp Integration Time	0.0	0.0 {s}	50.0	 P106 = 0.0: Linear accel/decel ramp P106 > 0.0: Adjusts S-ramp curve for smoother ramp
P IO1 (1)	Line Voltage Selection	1*	 Low (120, 200, 400 High (120, 240, 480 	0, 480VAC) 0, 600VAC)	* The default setting is 1 for all drives except when using "reset 50" (Parameter P199, selection 4) with 480V models. In this case, the default setting is 0.
P 108	Motor Overload	100	30 {%}	100	P108 = <u>motor current rating</u> x 100 SMV output rating Example: if motor = 3amps and SMV = 4amps, then P108 = 75%
		i	NOTE Do not set above rated motor current as listed on the motor dataplate. The motor the overload function of the SMV is UL approved as a motor protection device. If the lim power is cycled, the motor thermal state is reset to cold state. Cycling power after a overload fault could result in significantly reducing the motor life.		
P 109	Motor Overload Type	0	O Speed Compensatio No Speed Compens	on sation	

(1) Any changes to this parameter will not take effect until the drive is stopped





Code		Possibl	e Settings					
No.	Name	Default	Selection	IMPORTANT				
P I 10	Start Method	0	0 Normal					
			1 Start on Power-up	Drive will automatically start when power is applied.				
			2 Start with DC Brake	When start command is applied, drive will apply DC braking according to P174, P175 prior to starting the motor				
			3 Auto Restart	Drive will automatically restart after faults, or when power is applied.				
			4 Auto Restart with DC Brake	Combines settings 2 and 3				
	5 Flying Start/Restart #1		5 Flying Start/Restart #1	 Drive will automatically restart after faults, or when power is applied. After 3 failed attempts, drive will Auto Restart with DC brake. P110 = 5: Performs speed search, starting at Max Frequency (P103) 				
			6 Flying Start/Restart #2	 P110 = 6: Performs speed search, startin at the last output frequency prior to faultin or power loss If P111 = 0, a flying START is performed when a start command is applied. 				
		l	 NOTE P110 = 0, 2: Start command must be applied at least 2 seconds after power-up; <i>F_UF</i> fault will occur if start command is applied too soon. P110 = 1, 36: For automatic start/restart, the start source must be the terminal strip and the start command must be present. P110 = 2, 46: If P175=999.9, dc braking will be applied for 15s. P110 = 36: Drive will attempt 5 restarts; if all restart attempts fail, drive displays LC (fault lockout) and requires manual reset. 					
\triangle	WARNING! Automatic starting/res	starting ma	y cause damage to equipment and/or inju	ry to personnel! Automatic starting/restarting				
PIII	Stop Method	0	0 Coast	Drive's output will shut off immediately upon a stop command, allowing the motor to coast to a stop				
	1 Coast with DC Brake		1 Coast with DC Brake	The drive's output will shut off and then the DC Brake will activate (see P174, P175)				
			2 Ramp	The drive will ramp the motor to a stop according to P105 or P126.				
			3 Ramp with DC Brake	The drive will ramp the motor to 0 Hz and then the DC Brake will activate (see P174, P175)				
P I 12	Rotation	0	0 Forward Only	If PID mode is enabled, reverse direction is				
			1 Forward and Reverse	disabled (except for Jog).				





4.5.2 I/O Setup Parameters

Code		Possibl	e Settings	IMPORTANT	
No.	Name	Default	Selection	IMPORTANT	
P 120	Assertion Level	2	1 Low 2 High	P120 and the Assertion Level switch must both match the desired assertion level unless P100, P121P123 are all set to 0. Otherwise an F at the suit will occur.	
	TD 124 Input	0	0 Nono		
PIEI	Function	0	U NUTE	Disables input	
				For PID mode, see P204P205.	
P 122	TB-13B Input		2 AUTO Reference: 4-20 IIIA	For vector torque mode, see P330	
P 123	TB-13C Input		3 AUTO Reference: Preset	For frequency mode see P131P137, For PID mode, see P231P233, For torque mode see, P331P333	
	Function		4 AUTO Reference: MOP Up	 Normally open: Close input to increase or decrease speed, PID setpoint or torque 	
			5 AUTO Reference: MOP Down	setpoint.MOP Up is not active while in STOP	
			6 AUTO Reference: Keypad		
			7 AUTO Reference: Network		
			8 Control Select	Use when P100 = 4, 5 to switch between terminal strip control and local or remote keypad control.	
			9 Network Enable	Required to start the drive through the network.	
			10 Reverse Rotation	Open = Forward Closed = Reverse	
			11 Start Forward	See note for typical circuit	
			12 Start Reverse		
			13 Run Forward	See note for typical circuit	
			14 Run Reverse		
			15 Jog Forward	Jog Forward speed = P134	
			16 Jog Reverse	Jog Reverse speed = P135	
			17 Accel/Decel #2	Refer to parameters P125, P126	
			18 DC Brake	See P174; close input to override P175	
			19 Auxiliary Ramp to Stop	Normally closed: Opening input will ramp drive to STOP according to P127, even if P111 is set to Coast (0 or 1).	
			20 Clear Fault	Close to reset fault	
			21 External Fault F_EF	Normally closed circuit; open to trip	
			22 Inverse External Fault F_EF	Normally open circuit; close to trip	
Λ	WARNING!				

2. Jog overrides all STOP commands! To stop the drive while in Jog mode, the Jog input must be deactivated or a fault condition induced.





Code		Possible Settings				IMPORTANT					
No.	Name	Default	Selection					INIPOR			
i	NOTE • When input is activ When TB-13ATB overrides TB-13A. Settings 1014 ar If Start/Run/Jog Fo If Jog input is activ will STOP. • An F_RL fault will of the digital inpu • An F_IL fault will - TB-13ATB-13C - One input is set to • Typical control circ • If any input is set Run / Stop with Direction P121 = 10 • One input is REV • One input is set to • One input	ated, settii -13C are c Any other , e only valic rward and ated while occur if t ts (P121 occur unde settings a "MOP Up" 0 10 and a 0 11 or 12 uits are sh to 10, 12 of A	ngs 17 overrid onfigured for Au Auto Reference 1 in Terminal Str Start/Run/Jog R the drive is run he Assertion L& P123) are set i er the following re duplicated (er and another is p own below: or 14, P112 mus	le P101. to Referencess will have prior ip mode (P10) Reverse are bo ning, the drive evel switch (<i>A</i> to a value oth conditions: ach setting, ex- not set to "MOI et to 1114. ut is set for 13 st be set to 1 ff Start F Start P121 = 11	other than 1 ity over MOF 0 = 1, 4, 5). th activated, will enter Ju Lsw) positi er than 0. cept 0 and 2 Pown", or v 3 or 14. or Reverse a orward / Reverse 13A 13E 13A 13E 13A 13E	MOP 2. og n on c 3, ca vice-	P, TB-13C ove ve will STOP. node; when J does not ma an only be us versa. n to function	errides TB log input i tch the P ed once).	Run Forv Run Forv Run Rev 1 = 13, F	ated, driv ing and a vard / verse 122 = 14 3A 13E	e iny 1
P 125	Acceleration Time 2	20.0	0.0	{S}	3600	•	Selected usir	ng TB-13/	ATB-130	C (P121	
P 126	Deceleration Time 2	20.0	0.0	{S}	3600		P123 = 17) For S-ramp a	iccel/dece	el, adjust	P106	
P 127	Deceleration Time for Auxiliary Ramp to Stop	20.0	0.0	{s}	3600	•	Selected usir P123 = 19). For S-ramp a Once execute over P105 ar	ng TB-134 accel/dece ed, this ra ad P126.	ATB-130 el, adjust imp time l	C (P121 P106 has priori	ty
P 13 I	Preset Speed #1	0.0	0.0	{Hz}	500		PRESET	13A	13B	130	
P 132	Preset Speed #2	0.0	0.0	{Hz}	500		SPEED 1	Y	100		
P 133	Preset Speed #3	0.0	0.0	{Hz}	500		2		х		
P 134	Preset Speed #4	0.0	0.0	{Hz}	500		3			Х	
P 135	Preset Speed #5	0.0	0.0	{Hz}	500		4	X	X	 X	
P 136	Preset Speed #6	0.0	0.0	{Hz}	500		6		Х	X	
P IB7	Preset Speed #7	0.0	0.0	{Hz}	500		7	Х	Х	Х	





Code		Possibl	e Settings	IMPORTANT												
No.	Name	Default	Selection													
P 140	Relay Output TB-16, 17	0	0 None	Disables the output												
			1 Run	Energizes when the drive is running												
			2 Reverse	Energizes when reverse rotation is active												
			3 Fault	De-energizes when the drive trips, or power is removed												
			4 Inverse Fault	Energizes when the drive trips												
			5 Fault Lockout	P110 = 36: De-energizes if all restart attempts fail												
			6 At Speed	Energizes when output frequency = commanded frequency												
			7 Above Preset Speed #6	Energizes when output freq. > P136												
			8 Current Limit	Energizes when motor current = P171												
				9 Follower Loss (4-20 mA)	Energizes when 4-20 mA signal falls below 2 mA											
			10 Loss of Load	Energizes when motor load drops below P145; see also P146												
			11 Local Keypad Control Active													
			12 Terminal Strip Control Active	Energizes when the selected source is active												
			13 Remote Keypad Control Active	for start control												
			14 Network Control Active													
			15 Standard Reference Active	Energizes when P101 reference is active												
			16 Auto Reference Active	Energizes when Auto Reference is activated using TB-13 input; refer to P121P123												
			17 Sleep Mode Active	Refer to parameters P240P242												
			18 PID Feedback < Min. Alarm	Energizes when PID feedback signal < P214												
								- - - -	19					19	19 Inverse PID Feedback < Min. Alarm	De-energizes when PID feedback signal < P214
										20 PID Feedback > Max Alarm	Energizes when PID feedback signal > P215					
			21 Inverse PID Feedback > Max Alarm	De-energizes when PID feedback signal > P215												
			22 PID Feedback within Min/Max Alarm range	Energizes when PID feedback signal is within the Min/Max Alarm range; see P214, P215												
						2	23 PID Feedback outside Min/Max Alarm range	Energizes when PID feedback signal is outside the Min/Max Alarm range; see P214, P215								
			24 Reserved													
			25 Network Activated	Requires optional communication module (refer to the network module documentation).												





Code		Possible Settings				INADODTANT
No.	Name	Default	Se	ection		IMPORTANT
P 142	TB-14 Output	0	02	23 (same as P140)		
			24	Dynamic Braking		For use with Dynamic Braking option
			25	Network Activated		Requires optional communication module (refer to the network module documentation).
P 145	Loss of Load Threshold	0	0	{%}	200	P140, P142 = 10: Output will energize if motor load falls below P145 value longer than
P 146	Loss of Load Delay	0.0	0.0	{S}	240.0	P146 time
P 150	TB-30 Output	0	0	None		2-10 VDC signal can be converted to 4-20 mA
			1	0-10 VDC Output Frequ	ency	with a total circuit impedance of 500 Ω
			2	2-10 VDC Output Frequ	ency	
			3	0-10 VDC Load		
			4	2-10 VDC Load		
			5	0-10 VDC Torque		
			6	2-10 VDC Torque		
			7	0-10 VDC Power (kW)		
			8	2-10 VDC Power (kW)		
			9	Network Controlled		Requires optional communication module (refer to the network module documentation).
P 152	TB-30 Scaling: Frequency	60.0	3.0	{Hz}	2000	If $P150 = 1$ or 2, sets the frequency at which output equals 10 VDC
P 153	TB-30 Scaling: Load	200	10	{%}	500	If $P150 = 3$ or 4, sets the Load (as a percent of drive current rating) at which output equals 10 VDC.
P 154	TB-30 Scaling: Torque	100	10	{%}	1000	If $\text{P150}=5$ or 6, sets the Torque (as a percent of motor rated torque) at which output equals 10 VDC
P 155	TB-30 Scaling: Power (kW)	1.0	0.1	{kW}	200.0	If $P150 = 7$ or 8, sets the power at which output equals 10 VDC





4.5.3 Advanced Setup Parameters

Code		Possible Settings				
No.	Name	Default	Selection			IMPORTANT
P 160	Speed at Minimum Signal	0.0	-999.0	{Hz}	1000	P161
P 16 I	Speed at Maximum Signal	60.0	-999.0	{Hz}	1000	0V 10V ref (4mA) (20mA) P160
		i	NOTE • P160 sets th • P161 sets th • P160 or P16 direction! • P160 > P16	ne output frequ ne output frequ 11 < 0.0 Hz: Fc 1: Drive will re	ency at 0% ency at 100 r scaling pu act inversely	analog input % analog input rposes only; does not indicate opposite y to analog input signal
P 162	Analog Input Filter	0.01	0.00	{S}	10.00	Adjusts the filter on the analog inputs (TB-5 and TB-25) to reduce the effect of signal noise
P 163	TB-25 Loss Action	0	 No Action Fault F_Fol Go to Prese Speed refer PID feedbac PID setpoint Torque refe 	L t when TB-25 rence: P137 ck source: P13 t reference: P333	is: 37 233	 Selects the reaction to a loss of the 4-20 mA signal at TB-25. Signal is considered lost if it falls below 2 mA Digital outputs can also indicate a loss of 4-20 mA signal; refer to P140, P142
P 166	Carrier Frequency	See Notes	 4 kHz 6 kHz 8 kHz 10 kHz 			 As carrier frequency is increased, motor noise is decreased Observe derating in Section 2.2.2 and 2.2.3 Automatic shift to 4 kHz at 120% load NEMA 4X (IP65) Models: Default = 0 (4kHz) NEMA 1 (IP31) Models: Default = 1 (6kHz)
P 167(1)	Base Frequency	60.0	10.0	{Hz}	1500	
P 168	Fixed Boost		0.0	{%}	30.0	P168 0 0 0 P167 t V0112
		i	 NOTE P167 = rate P168 = defa 	d motor freque	ency for stan	idard applications ve rating
P 169	Accel Boost	0.0	0.0	{%}	20.0	Accel Boost is only active during acceleration

(1) Any changes to this parameter will not take effect until the drive is stopped





Code		Possible Settings					IMPOPTANT	
No.	Name	Default	Selection				IMPORTANT	
Р ПО	Slip Compensation	0.0	0.0	{%}	10.0	lno lor co	crease P170 until the motor speed no nger changes between no load and full load nditions.	
Р П (")	Current Limit	200	30	{%}	CLim _{max}	•	When the limit is reached, the drive displays $L_{\rm L}$, and either the acceleration time increases or the output frequency decreases. Digital outputs can also indicate when the limit is reached; refer to P140, P142. Refer to Section 2.2 for CLim _{max}	
Р ПЧ	DC Brake Voltage	0.0	0.0	{%}	30.0	Se vo	tting is a percent of the nominal DC bus Itage.	
Р П5	DC Brake Time	0.0	0.0	{S}	999.9			
		i	NOTE CONFIRM MOTO	OR SUITABILIT	Y FOR USE \	WIT	H DC BRAKING	
			 DC Brake voltage (P174) is applied for the time specified by P175 with the following exceptions: If P111=1, 3 and P175=999.9 the brake voltage will be applied continuously until a run or fault condition occurs. If P110=2, 46 and P175=999.9, brake voltage will be applied for 15s If P121P123=18 and the corresponding TB-13 input is CLOSED, brake voltage will be applied until the TB 12 ionut is OPENFC are forth condition accurs. 					
P 118	Display Frequency Multiplier	0.00	0.00		650.00	•	Allows frequency display to be scaled P178 = 0.00: Scaling disabled P178 > 0.00: Display = Actual Frequency X P178	
		i	Example: If P1	78 = 29.17 ar	id actual free	que	ncy = 60 Hz, then Drive displays 1750 (rpm)	
P 119	Run Screen Display	0	0 {Parameter	Number}	599	•	0 = Normal Run Screen, this display depends on mode of operation. Refer to Section 4.2. Other selections choose a diagnostic parameter to display (P501P599).	
P 18 I	Skip frequency 1	0.0	0.0	{Hz}	500	•	Drive will not run in the defined skip range;	
P 182	Skip frequency 2	0.0	0.0	{Hz}	500	1	used to skip over frequencies that cause mechanical vibration	
P 184	Skip frequency bandwidth	0.0	0.0	{Hz}	10.0	•	P181 and P182 define the start of the skip ranges P184 > 0 defines the bandwidth of both ranges.	
		i	NOTE Bandwidth (Hz) Example: P181	$= f_s (Hz) + P1$ = 18 Hz and	84 (Hz) P184 = 4 Hi	f _s z; s	= P181 or P182 kip range is from 18 to 22 Hz	

(1) Any changes to this parameter will not take effect until the drive is stopped





Code		Possibl	e Settings	IMPODIANI	
No.	Name	Default	Selection	IMPORTANT	
P 194	Password	225	0000 9999	 Must enter password to access parameters P194 = 0000: Disables password 	
P 197	Clear Fault History	0	0 No Action		
			1 Clear Fault History		
P 199	Program Selection		0 Operate from User settings		
			1 Operate from OEM settings	Refer to Notes 1, 2 and 3	
			2 Reset to OEM default settings	Refer to Note 1	
	 3 Reset to 60 Hz default settings 4 Reset to 50 Hz default settings 		 Refer to Note 4 Parameters are reset to the defaults listed in this manual. For P199=4, the following exceptions apply: p102_p152_p151_p167_s0_0 Hz 		
			4 Reset to 50 Hz default settings	- P105, P105, P107 = 50.0 ft2 - P304 = 50 Hz; - P305 = 1450 RPM - P107 = 0 (480 V drives only)	
			5 Translate	Refer to Note 5	
		\triangle	WARNING! Modification of P199 can affect drive func- may be disabled! Check P100 and P121	tionality! STOP and EXTERNAL FAULT circuitry P123	
		Ì	Note 1 If the EPM does not contain valid OEM se P199 is set to 1 or 2. Note 2 When P199 is set to 1, the drive operates Module and no other parameters can be in Note 3 Auto Calibration is not possible when ope Note 4 Reset 60 and Reset 50 will set the Assert to be reset for the digital input devices be the Assertion switch are not set identicall Note 5 If an EPM that contains data from a previ • The drive will operate according to the changed (cE will be displayed if attem • To update the EPM to the current softw • now be changed but the EPM is incom	ttings, a flashing <i>GF</i> will be displayed when a from the OEM settings stored in the EPM changed (<i>GE</i> will be displayed if attempted). rating from OEM Settings. ion Level (P120) to "2" (High). P120 may need ing used. An <i>F_RL</i> fault may occur if P120 and y. bus compatible software version is installed: a previous data, but parameters cannot be pted) vare version, set P199 = 5. The parameters can patible with previous software revisions.	





Code Possible Settings		MEODIANT			
No.	Name	Default	Selection		IMPORTANT
P200	PID Mode	0	0 Disabled 1 Normal-acting		 Normal-acting: As feedback increases, motor speed decreases Reverse-acting: As feedback increases, motor speed increases
			2 Reverse-acting		 PID mode is disabled in Vector Torque mode (P300 = 5)
		ĺ	NOTE To activate PID mode, of the Auto Reference that setpoint reference uses fault will occur. Example: The desired I (Auto Reference: Keypar • TB-13x = closed: PIC • TB-13x = open: PID • reference selected in	ne of the TB-13 in matches the desithe same analog PID setpoint referently:) mode is active mode is disabled P101.	nputs (P121P123) must be used to select red PID setpoint reference. If the selected PID signal as the PID feedback (P201), an $F_{-}I_{-}L$ ence is the keypad (▲ and ▼). Set TB-13x = 6 and the drive speed will be controlled by the
P20 I	PID Feedback Source	0	0 4-20 mA (TB-25) 1 0-10 VDC (TB-5)		Must be set to match the PID feedback signal
9202	PID Decimal Point	1	 PID Display = XXXX PID Display = XXX.X PID Display = XX.XX PID Display = X.XXX PID Display = .XXXX PID Display = .XXXX 		Applies to P204, P205, P214, P215, P231 P233, P242, P522, P523
P204	Feedback at Minimum Signal	0.0	-99.9	3100.0	Set to match the range of the feedback signal being used
P205	Feedback at Maximum Signal	100.0	-99.9	3100.0	Example: Feedback signal is 0 - 300 PSI; P204 = 0.0, P205 = 300.0
רסכק	Proportional Gain	5.0	0.0 {%}	100.0	Used to tune the PID loop:
P208	Integral Gain	0.0	0.0 {s}	20.0	Increase P207 until system becomes unstable then decrease P207 by 10-15%
P209	Derivative Gain	0.0	0.0 {s}	20.0	Next, increase P208 until feedback matches setpoint If required, increase P209 to compensate for sudden changes in feedback
		i	 NOTE Derivative Gain is very sensitive to noise on the feedback signal and must be used with care Derivative Gain is not normally required in pump and fan applications 		
P2 10	PID Setpoint Ramp	20.0	0.0 {s}	100.0	 Time of setpoint change from P204 to P205 or vice versa. Used to smooth the transition from one PID setpoint to another, such as when using the Preset PID Setpoints (P231P233)

4.5.4 PID Parameters





Code		Possible Settings			IMPORTANT	
No.	Name	Default	Selection			IMPORTANT
P2 14	Minimum Alarm	0.0	P204		P205	Use with P140, P142 = 1823
P2 15	Maximum Alarm	0.0	P204		P205	
1 E59	Preset PID Setpoint #1	0.0	P204		P205	TB-13A activated; $P121 = 3$ and $P200 = 1$ or 2
P232	Preset PID Setpoint #2	0.0	P204		P205	TB-13B activated; $P122 = 3$ and $P200 = 1$ or 2
P233	Preset PID Setpoint #3	0.0	P204		P205	TB-13C activated; $P123 = 3$ and $P200 = 1$ or 2
P240	Sleep Threshold	0.0	0.0	{Hz}	500.0	• If drive speed < P240 for longer than P241,
P24 I	Sleep Delay	30.0	0.0	{S}	300.0	output frequency = 0.0 Hz; drive display = 5LP
P242	Sleep Bandwidth	0.0	0.0 Where: B _{max} = I	(P205 - P204)I	B _{max}	 P240 = 0.0: Sleep mode is disabled. P200 = 02: Drive will start again when speed command is above P240 P242 > 0.0: Drive will restart when the PID feedback differs from the setpoint by more than the value of P242 or when the PID loop requires a speed above P240.





Code		Possible Settings				
No.	Name	Default	Selectio	n		IMPORTANT
P300 (1)	Drive Mode	0	0 Consta	nt V/Hz		Constant torque V/Hz control for general applications
			1 Variable V/Hz			Variable torque V/Hz control for centrifugal pump and fan applications
			2 Enhand	ced Constant V/H	lz	For single or multiple motor applications that
			3 Enhanced Variable V/Hz		Z	require better performance than settings 0 or 1, but cannot use Vector mode, due to: Missing required motor data Vector mode causing unstable motor operation
			4 Vector	Speed		For single-motor applications requiring higher starting torque and speed regulation
			5 Vector	Torque		For single-motor applications requiring torque control independent of speed
		1	NOTE To configure the drive for either Vector m P300 = 4, 5: - Set P302P306 according to mol - Set P399 = 1 - Make sure motor is cold (20° - 25 - Display will indicate <i>LFL</i> for abou - Once the calibration is complete, Start command to actually start the - If an attempt is made to start the performing the Motor Calibration, operate • P300 = 2, 3: Same as above but only			ode or Enhanced V/Hz mode: or nameplate of C) and apply a Start command t 40 seconds the display will indicate 5±oP ; apply another the motor drive in Vector or Enhanced V/Hz mode before the drive will display F_n Id and will not need to set P302P304
P302(1)	Motor Rated Voltage		0	{V}	600	Default setting = drive rating
P303(1)	Motor Rated Current		0.0	{A}	500.0	Set to motor nameplate data
P304(1)	Motor Rated Frequency	60	0	{Hz}	1000	
P305(1)	Motor Rated Speed	1750	300	{RPM}	65000	Set to motor nameplate data
P306(1)	Motor Cosine Phi	0.80	0.40		0.99	
		i	NOTE If motor cosine phi is not known, use one of the following formulas: cos phi = motor Watts / (motor efficiency X P302 X P303 X 1.732) cos phi = cos [sin ¹ (magnetizing current / motor current)]			e of the following formulas: y X P302 X P303 X 1.732) / motor current)]
P3 10(1)	Motor Stator Resistance	0.00	0.00	$\{\Omega\}$	64.00	Will be automatically programmed by P399 Changing these settings can adversely
P3 1 ⁽¹⁾	Motor Stator Inductance	0.0	0.0	{mH}	2000	affect performance. Contact factory technical support prior to changing.
P330	Torque Limit	100	0	{%}	400	When $P300 = 5$, sets the maximum output torque.

4.5.5 Vector Parameters

(1) Any changes to this parameter will not take effect until the drive is stopped





Code		Possible Settings				
No.	Name	Default	Sele	ection		IMPORTANT
P33 I	Preset Torque Setpoint #1	100	0	{%}	400	TB-13A activated; P121 = 3 and P300 = 5
P332	Preset Torque Setpoint #2	100	0	{%}	400	TB-13B activated; $P122 = 3$ and $P300 = 5$
P333	Preset Torque Setpoint #3	100	0	{%}	400	TB-13C activated; P123 = 3 and P300 = 5
P340(1)	Current Loop P Gain	0.25	0.00		16.0	
P34 (1)	Current Loop I Gain	65	12	{ms}	9990	Changing these settings can adversely affect performance. Contact factory technical support
P342 ⁽¹⁾	Speed Loop Adjustment	0.0	0.0	{%}	20.0	prior to changing.
P399	Motor Auto- calibration	- 0 0 Calibration Not Done 1 Calibration Enabled 2 Calibration Complete		 If P300 = 25, motor calibration must be performed, but motor data must be programmed first. An alternating <i>CRL / Err</i> will occur if: - motor calibration is attempted with P300 = 0 or 1 - motor calibration is attempted before programming motor data 		
		NOTE To run the Auto Calibration: - Set P302P306 according to motor nameplate - Set P399 = 1 - Make sure motor is cold (20° - 25° C) - Apply a Start command - Display will indicate <i>CRL</i> for about 40 seconds - Once the calibration is complete, the display will indicate <i>5LoP</i> ; apply another Start command to actually start the motor - Parameter P399 will now be set to 2			r nameplate C) 40 seconds e display will indicate 5±¤P ; apply start the motor 2.	

(1) Any changes to this parameter will not take effect until the drive is stopped

4.5.6 Network Parameters

Code		Possibl	e Settings	IMPORTANT
No.	Name	Default	Selection	IMPORTANT
P400	Network Protocol		0 Not Active	
			1 Remote Keypad	
			2 Modbus RTU	
			3 CANopen	This parameter will only display the selection for the module that is installed
			4 DeviceNet	
			5 Ethernet	
			6 Profibus	
P40 1 P499 Modu		Module S	pecific Parameters	Refer to the Reference Guide specific to the module installed.







4.5.7 Diagnostic Parameters

Code		Display Range				
No.	Name	(READ ONLY))	IMFORTANT	
P500	Fault History				 Displays the last 8 faults Format: n.xxx where: n = 18; 1 is the newest fault xxx = fault message (without the F.) Refer to Section 5.3 	
P50 I	Software version				Format: x.yz	
P502	Drive ID				A flashing display indicates that the Drive ID stored in the EPM does not match the drive model it is plugged into.	
P503	Internal Code				Alternating Display: xxx-; -yy	
P505	DC Bus Voltage	0	{VDC}	1500		
P506	Motor Voltage	0	{VAC}	1000		
P507	Load	0	{%}	255	Motor load as % of drive's output current rating. Refer to Section 2.2.	
P508	Motor Current	0.0	{A}	1000	Actual motor current	
P509	Torque	0	{%}	500	Torque as % of motor rated torque (vector mode only)	
P5 10	kW	0.00	{kW}	650.0		
P5 I I	kWh	0.0	{kWh}	9999999	Alternating display: xxx-; yyyy when value exceeds 9999	
P5 12	Heatsink Temp	0	{°C}	150	Heatsink temperature	
P520	0-10 VDC Input	0.0	{VDC}	10.0	Actual value of signal at TB-5	
P52 I	4-20 mA Input	0.0	{mA}	20.0	Actual value of signal at TB-25	
P522	TB-5 Feedback	P204		P205	TB-5 signal value scaled to PID feedback units	
P523	TB-25 Feedback	P204		P205	TB-25 signal value scaled to PID feedback units	
P525	Analog Output	0	{VDC}	10.0	Refer to parameters P150P155	
P527	Actual Output Frequency	0	{Hz}	500.0		
P528	Network Speed Command	0	{Hz}	500.0	Command speed if (Auto: Network) is selected as the speed source	
P530	Terminal and Protection Status				Indicates terminal status using segments of the LED display. (Refer to Section 4.5.7.1)	
P53 I	Keypad Status				Indicates keypad button status using segments of the LED display. (Refer to Section 4.5.7.2)	
P540	Total Run Time	0	{h}	99999999	Alternating display: xxx-; yyyy when value exceeds 9999	
P54 I	Total Power On Time	0	{h}	99999999		





4.5.7.1 Terminal and Protection Status Display

Parameter P530 allows monitoring of the control terminal points and common drive conditions:

An illuminated LED segment indicates:

- the protective circuit is active (LED 1)
- the Logic Assertion Switch is set to High (+)
- input terminal is asserted (LED 2)
- output terminal is energized (LED 4)

• the Charge Relay is not a terminal, this segment will be illuminated when the Charge Relay is energized (LED 4).



4.5.7.2 Keypad Status Display

Parameter P531 allows monitoring of the keypad pushbuttons: An illuminated LED segment indicates when the button is depressed.







5 Troubleshooting and Diagnostics

5.1 Status/Warning Messages

Status / Warning		Cause	Remedy
br	DC-injection brake active	DC-injection brake activated • activation of digital input (P121P123 = 18) • automatically (P110 = 2, 46) • automatically (P111 = 1, 3)	Deactivate DC-injection brake deactivate digital input automatically after P175 time has expired
ЬF	Drive ID warning	The Drive ID (P502) stored on the EPM does not match the drive model.	 Verify motor data (P302P306) and perform Auto Calibration. Set drive mode (P300) to 0 or 1 Reset the drive (P199 to 3 or 4) and reprogram.
EAL	Motor Auto-calibration is being performed	See P300, P399	
сE	An EPM that contains valid data from a previous software version has been installed	An attempt was made to change parameter settings	Parameter settings can only be changed after the EPM data is converted to the current version (P199 = 5)
EL	Current Limit (P171) reached	Motor overload	 Increase P171 Verify drive/motor are proper size for application
dEC	Decel Override	The drive has stopped decelerating to avoid tripping into HF fault, due to excessive motor regen (2 sec max).	If drive trips into <i>HF</i> fault: Increase P105, P126 Install Dynamic Braking option
Err	Error	Invalid data was entered, or an invalid command was attempted	
FEL	Fast Current Limit	Overload	Verify drive/motor are proper size for application
FSE	Flying Restart Attempt after Fault	P110 = 5,6	
GE	OEM Settings Operation warning	An attempt was made to change parameter settings while the drive is operating in OEM Settings mode (P199 = 1)	In OEM Settings mode, making changes to parameters is not permitted
GF	OEM Defaults data warning	An attempt was made to use (or reset to) the OEM default settings (P199 = 1 or 2) using an EPM without valid OEM data.	Install an EPM containing valid OEM Defaults data
LC	Fault Lockout	The drive attempted 5 restarts after a fault but all attempts were unsuccessful $(P110 = 36)$	 Drive requires manual reset Check Fault History (P500) and correct fault condition
PdEC	PID Deceleration Status	PID setpoint has finished its ramp but the drive is still decelerating to a stop.	





	Status / Warning	Cause	Remedy
PId	PID Mode Active	Drive has been put into PID Mode. Refer to parameter P200.	
5LP	Sleep Mode is active	Refer to parameters P240P242	
5P	Start Pending	The drive has tripped into a fault and will automatically restart ($P110 = 36$)	To disable Auto-Restart, set P110 = 02
SPd	PID Mode disabled.	Drive has been taken out of PID Mode. Refer to parameter P200.	
StoP	Output frequency = 0 Hz (outputs U, V, W inhibited)	Stop has been commanded from the keypad, terminal strip, or network	Apply Start command (Start Control source depends on P100)

5.2 Drive Configuration Messages

When the Mode button is pressed and held, the drive's display will provide a 4-digit code that indicates how the drive is configured. If the drive is in a Stop state when this is done, then the display will also indicate which control source commanded the drive to Stop (the two displays will alternate every second).

Configuration Display						
Format = x.y.zz	x = Control Source:	y = Mode:	zz = Reference:			
	L = Local Keypad E = Terminal Strip r = Remote Keypad n = Network	5 = Speed mode P = PID mode L = Vector Torque mode	$\begin{array}{l} \boldsymbol{LP} = \text{Keypad} \blacktriangle \boldsymbol{\nabla} \\ \boldsymbol{EU} = 0.10 \text{ VDC (TB-5)} \\ \boldsymbol{E} \ \boldsymbol{I} = 4.20 \text{ mA (TB-25)} \\ \boldsymbol{JL} = Jog \\ \boldsymbol{nL} = \text{Network} \\ \boldsymbol{DP} = \text{MOP} \\ \boldsymbol{P} \ \boldsymbol{I} = - \boldsymbol{PT} = \text{Preset } 17 \end{array}$			
	Example: • L_5_CP = Local Keypad Start control, Speed mode, Keypad speed reference • L_P_EU = Terminal Strip Start control, PID mode, 0-10 VDC setpoint reference • n_L_P2 = Network Start control, Vector Torque mode, Preset Torque #2 reference					
Stop Source Display						
Format = x_5£P	 L_5LP = Stop command came from Local Keypad L_5LP = Stop command came from Terminal Strip r_5LP = Stop command came from Remote Keypad n_5LP = Stop command came from Network 					





5.3 Fault Messages

The messages below show how they will appear on the display when the drive trips. When looking at the Fault History (P500), the F, will not appear in the fault message.

	Fault	Cause	Remedy ⁽¹⁾
F_AF	High Temperature fault	Drive is too hot inside	Reduce drive loadImprove cooling
F_AL	Assertion Level fault	 Assertion Level switch is changed during operation P120 is changed during operation P100 or P121P123 are set to a value other than 0 and P120 does not match the Assertion Level Switch. 	 Make sure the Assertion Level switch and P120 are both set for the type of input devices being used, prior to setting P100 or P121P123. Refer to Section 3.2.3 and P120.
F_bF	Personality fault	Drive Hardware	Cycle Power
F_[F	Control fault	An EPM has been installed that is either blank or corrupted	 Power down and install EPM with valid data Reset the drive back to defaults (P199)
F_cF	Incompatible EPM fault	An EPM has been installed that contains data from an incompatible parameter version	 3, 4) and then re-program If problem persists, contact factory technical support
F_dbF	Dynamic Braking fault	Dynamic braking resistors are overheating	 Increase active decel time (P105, P126, P127). Check mains voltage and P107
F_EF	External fault	 P121P123 = 21 and that digital input has been opened. P121P123 = 22 and that digital input has been closed. 	Correct the external fault condition Make sure digital input is set properly for NC or NO circuit
F_F I	EPM fault	EPM missing or defective	Power down and replace EPM
F_F2 F_F 12	Internal faults		Contact factory technical support
F_Fnr	Invalid message received	 A network message was received while in Remote Keypad mode A remote keypad message was received while in Network mode 	Only the remote keypad or the network can be connected at one time; see P100
F_FoL	Loss of 4-20 mA signal fault	4-20 mA signal (at TB-25) is below 2 mA (P163 = 1)	Check signal/signal wire
F_GF	OEM Defaults data fault	Drive is powered up with P199 =1 and OEM settings in the EPM are not valid.	Install an EPM containing valid OEM Defaults data or change P199 to 0.
F_HF	High DC Bus Voltage fault	Mains voltage is too high	Check mains voltage and P107
		Decel time is too short, or too much regen from motor	Increase active decel time (P105, P126, P127) or install Dynamic Braking option

(1) The drive can only be restarted if the error message has been reset





Fault		Cause	Remedy ⁽¹⁾
F_ IL	Digital Input Configuration fault (P121	More than one digital input set for the same function	Each setting can only be used once (except settings 0 and 3)
	P123)	Only one digital input configured for MOP function (Up, Down)	One input must be set to MOP Up, another must be set to MOP Down
		PID mode is entered with setpoint reference and feedback source set to the same analog signal	Change PID setpoint reference (P121 P123) or feedback source (P201).
		One of the digital inputs (P121P123) is set to 10 and another is set to 1114.	
		One of the digital inputs (P121P123) is set to 11 or 12 and another is set to 13 or 14.	Reconfigure digital inputs
		PID enabled in Vector Torque mode (P200 $= 1 \text{ or } 2 \text{ and } P300 = 5$)	PID cannot be used in Vector Torque mode
F_JF	Remote keypad fault	Remote keypad disconnected	Check remote keypad connections
F_LF	Low DC Bus Voltage fault	Mains voltage too low	Check mains voltage
F_n ld	No Motor ID fault	An attempt was made to start the drive in Vector or Enhanced V/Hz mode prior to performing the Motor Auto-calibration	See P300P399 for Drive Mode setup and calibration.
F_ntF	Module communication fault	Communication failure between drive and Network Module.	Check module connections
F_nF I F_nF9	Network Faults	Refer to the module documentation. for Causes and Remedies.	
F_OF	Output fault:	Output short circuit	Check motor/motor cable
	Transistor fault	Acceleration time too short	Increase P104, P125
		Severe motor overload, due to: • Mechanical problem • Drive/motor too small for application	 Check machine / system Verify drive/motor are proper size for application
		Boost values too high	Decrease P168, P169
		Excessive capacitive charging current from the motor cable	 Use shorter motor cables with lower charging current Use low capacitance motor cables Install reactor between motor and drive.
		Failed output transistor	Contact factory technical support
F_OF I	Output fault: Ground fault	Grounded motor phase	Check motor and motor cable
		Excessive capacitive charging current of the motor cable	Use shorter motor cables with lower charging current
F_PF	Motor Overload fault	Excessive motor load for too long	 Verify proper setting of P108 Verify drive and motor are proper size for application

(1) The drive can only be restarted if the error message has been reset





	Fault	Cause	Remedy ⁽¹⁾
F_rF	Flying Restart fault	Controller was unable to synchronize with the motor during restart attempt; (P110 = 5 or 6).	Check motor / load
F_5F	Single-Phase fault	A mains phase has been lost.	Check mains voltage
F_UF	Start fault	Start command was present when power was applied (P110 = 0 or 2).	 Must wait at least 2 seconds after power-up to apply Start command Consider alternate starting method (Refer to parameter P110).

(1) The drive can only be restarted if the error message has been reset.



AC Technology Corporation

630 Douglas Street • Uxbridge, MA 01569 • USA Sales: 800 217-9100 • Service: 508 278-9100 www.actech.com

(SV01D)